


# Piezo-electric devices


# The piezo-electric effect

- The piezo-electric ('pressure of electricity') effect couples deformation of a material with electrical output. The effect works in both directions.
- Quartz is one of the naturally occurring materials to display piezo electric properties, but several man-made piezo electric materials with stronger properties have been developed.
- Piezo-electric materials are solids, the effect arising from their molecular crystal structure. Many are ceramics.

# The piezo-electric effect - basic




- Compressing (or expanding) the piezo material will produce an electrical output



- Applying an electrical signal will cause the piezo material to deform

# Piezo devices



- Piezo electric devices are used in many everyday products, such as buzzers and speakers, microphones, camera lens motors, diesel injectors, accelerometers, etc


# Piezo devices



Piezo accelerometers



Piezo diesel injector




Piezo pressure sensor



University of  
BRISTOL


DEPARTMENT OF  
aerospace  
engineering

# Simplified physics – crystal structure




- The bonds of the crystal structure result in the constituent elements becoming polarised locally.
- Although the crystal structure has overall charge neutrality, deformation of the structure causes movement of individual charged elements within the structure.

# Simplified physics – crystal structure



- When piezo electric materials are deformed there is a net movement of elements with a particular charge in a particular direction.
- Movement of charged particles = electric current.


# Simplified physics – crystal structure



- Applying an electric field will result in charged elements attempting to migrate in the direction of the field, hence the crystal structure will deform.
- The particular crystal structure is vital in producing a strong piezo electric effect. Hence a large research effort is dedicated to developing new piezo materials.




# Simplified physics – crystal structure



- The particular crystal structure is vital in producing a strong piezo electric effect. Hence a large research effort is dedicated to developing new piezo materials.
- In real piezo materials the net charge dislocation can occur in several axes, including that of the applied force – more of this later.

# Simplified physics



Random crystallite, or grain orientation. These are known as 'Weiss domains'

- At a bulk material level, most piezo materials are polycrystalline.
- This random orientation of crystallite regions produces constructive and destructive summation of the net charge dislocation, reducing or destroying the piezo effect.




University of  
BRISTOL


DEPARTMENT OF  
aerospace  
engineering

# Crystal Structures


Crystalline




Polycrystalline



Amorphous




# Simplified physics



Grains aligned after polarisation

- Materials naturally tend towards a random orientation of Weiss domains as it minimises internal energy.
- To improve the strength of the piezo electric effect, material is polarised by applying a very high electric field – this tends to align the domains.


# Simplified physics



Grains aligned after polarisation

- The alignment can be reversed by;
  - Mechanical overloading
  - Electrical overloading
  - Heating material above Currie temperature.
- An even stronger piezo electric effect can be achieved by growing single crystals of piezo material, but that is a complex business.

# PZT



- One of the most commonly encountered piezo materials is 'PZT' – Lead Zirconate Titanate.
- This ceramic is usually sintered – material in powder form is compressed into a shape and heated to a temperature at which fuses particles together.
- Sintering is done above the Currie temperature so the material must be polarised.

# Modelling Piezo

- In the piezo material a mechanical displacement causes electric charge to moved.

***By definition;***                      *Current =  $\Delta$ Charge / time*

***So;***                      *Current  $\propto \Delta$ Displacement / time*


***Hence;***                      *Current  $\propto$  Velocity*

*This points to the impedance analogy, so make everything ‘square up’ with we set;*

*Force  $\propto$  Voltage*

# Piezo relations – forward effect

- We can represent the *forward effect* of piezo electric coupling as a current proportional to an applied velocity:



Where;  $i(t) \propto v(t)$

$$i(t) = p_f v(t)$$

↖  
We can define the forward coupling constant

- But this leaves us with a paradox: current must flow somewhere, so what happens if we deform the piezo element but leave it open circuited?




# Piezo relations – forward effect

- If the current isn't flowing out of the material then logically charge must be stored internally.
- The ability of a body to store charge is **Capacitance**.

**Electrically:**      $\text{Capacitance} = \text{charge} / \text{voltage}$


**As a material property :**      $\text{Capacitance} = \epsilon * \text{area} / \text{length}$

Where ' $\epsilon$ ' is the permittivity of the material, some times called 'dielectric constant', and often given in the form  $\epsilon_0 \epsilon_r$ , where  $\epsilon_0$  is the permittivity of free space.



# Piezo relations – forward effect

- Thus our basic model of *forward coupling* is a current source proportional to the driving velocity, in parallel with a capacitance formed by the piezo material itself.



Where:  $i(t) = v(t)P_f$


and:  $e(t) = \frac{1}{c_p} \int i(t) dt$

so:  $e(t) = \frac{p_f}{c_p} \int v(t) dt$

- An applied velocity causes a current which in turn generates a voltage across the piezo material's internal capacitance.***

# Piezo relations – forward effect

- If we add an electrical load on the output then the current remains the same for a given velocity, but the resultant voltage is different:



**Where:**  $i(t) = v(t)P_f$

**but now:**  $i(t) = \frac{e(t)}{R} + C_p \frac{de(t)}{dt}$

Since we know that this differential equation is easier handled in the frequency domain, we convert:

$$I(s) = V(s)P_f$$


$$I(s) = \frac{E(s)}{R} + C_p s E(s)$$

$$V(s)P_f = \frac{E(s)}{R} + C_p s E(s)$$

**so:**  $\frac{E}{V} = \frac{p_f}{\frac{1}{R} + j\omega C_p} = \frac{p_f/C_p}{\frac{1}{RC_p} + j\omega}$

# Piezo relations – converse effect

- But we also know that applying an electrical field to piezo material produces a mechanical force – the *converse effect*.



**Where:**  $f(t) \propto e(t)$


$$f(t) = p_c e(t)$$

converse constant

- Applying thinking similar to forward case, what happens if we apply a force to an mechanically unconstrained piezo element?

# Piezo relations – converse effect

- Simple - it deforms!



**Where;**  $f(t) = p_c e(t)$


**And**  $\Delta l = \frac{f(t)}{k_m}$

**so**  $\Delta l = \frac{p_c e(t)}{k_m}$

- *Applying an electric field creates a force which deforms the piezo material against it's own stiffness.*
- If we add additional mechanical structure then, similar to adding more components on the electrical side, the force is applied to the new structure and a differing deformation occurs.

# Piezo model


- Both the forward and converse effects happen together, so we can build a complete model of our piezo device



- What about  $p_c$  and  $p_f$ ?
- It is easy to prove that for power balance, they are equal.

# Piezo model

- Using a single coupling constant and adding in some mechanical loss and some electrical loss (always inevitable), we can describe the piezo device.



# Piezo coefficients – ‘g’ and ‘d’


- Piezo materials are commonly defined by manufacturers with two coefficients – ‘g’ and ‘d’.
- Note they are slightly more than the ‘coupling constant’ we have looked at so far with as they incorporate material properties: the material cannot be separated from the transduction effect, hence it often makes sense to do it this way.
- The coefficients are normalised to the size of the piezo element so comparison can be made of material properties.

**‘Voltage constant’ g;**       $g = \frac{\text{field}}{\text{applied stress}} = \frac{\text{strain}}{\text{applied charge density}}$

**‘Charge constant’ d;**       $d = \frac{\text{strain}}{\text{applied field}} = \frac{\text{charge density}}{\text{applied stress}}$




# Piezo coefficients – normalised variables



<b><i>Variable</i></b>		<b><i>Normalised Variable</i></b>
Displacement	➡	Strain = $\frac{\text{Change in length}}{\text{Length}}$
Force	➡	Stress = $\frac{\text{Force}}{\text{Cross section}}$
Voltage	➡	Electric field = $\frac{\text{Voltage}}{\text{Length}}$
Charge (Current)	➡	Charge density = $\frac{\text{Charge}}{\text{Cross section}}$

# Piezo coupling constants - parameters



## ***Parameter***

## ***Normalised Parameter***

$$\text{Stiffness} = \frac{\text{Force}}{\text{Change in length}}$$





$$\text{Elastic modulus} = \frac{\text{Stress}}{\text{Strain}}$$

$$\text{Capacitance} = \frac{\text{Charge}}{\text{Voltage}}$$



$$\text{Permittivity} = \frac{\text{Charge density}}{\text{Electric field}}$$

# Piezo coupling constants - definitions




*Note: this diagram is not implying that applying a force to a stiffness gives a velocity (it produces displacement), nor current to capacitance a voltage etc. It is drawn to preserve power producing couplets*

# Piezo coupling constants - definitions

$$g = \frac{\text{field}}{\text{applied stress}} = \frac{\text{strain}}{\text{applied charge density}}$$

$$d = \frac{\text{strain}}{\text{applied field}} = \frac{\text{charge density}}{\text{applied stress}}$$



# Piezo coupling constants


- As 'd' and 'g' are normalised to the area and length, they provide a good comparison of materials (as opposed to a particular device which is materials + geometry)
- By introducing the relations between stress and strain (elastic modulus) plus field and charge density (permittivity) it is possible to derive relations between d, g and the constant we defined in our model:

$$p = \frac{A}{l} Y d = \frac{A}{l} Y \epsilon g$$

# Piezo coupling constants

- 'd' and 'g' give a guide to behaviour in common applications, although it should be noted they are sometimes invalidated by additional mechanical or electrical components.
- The 'd' constant considers cases where we have applied a voltage, or the result is charge. Neither of these scenarios requires knowledge of the capacitance. Hence the 'd' constant only takes mechanical compliance into account. *This is useful when the piezo device is used as a sensor for instance to measure force.*
- The 'g' constant consider the cases where we need to convert both input and outputs via compliance and capacitance and vice-versa. Hence it takes both into account. *This is useful when the piezo device is used as an actuator.*

# Piezo coupling constants - axes



- The piezo electric effect can occur in orthogonal axes, as well as in line with the excitation.
- Coefficient have subscripts which indicate which i.e.  $d_{11}$   $d_{13}$   $g_{33}$

# More piezo constants.....


- In addition to the coupling terms, manufactures will often indicate loss.
- Unhelpfully, this is often called the electromechanical coupling coefficient (this is a different definition of the term than we will encounter elsewhere)

$$k = \frac{\sqrt{\text{mech\_energy\_input}}}{\sqrt{\text{Electrical\_energy\_output}}}$$



# Piezo compared to foil strain gauge

- What are the key differences between them?



# Piezo compared to foil strain gauge

- The mechanical input to the piezo device 'sees' the electrical output; The mechanical input to the strain gauge is oblivious to the electrical side.
- The piezo device has reciprocal conversion processes; the strain gauge system only works in one direction.
- Energy flows from one side of the piezo device to the other; No energy passes across the strain gauge mech/electrical interface.

# Piezo compared to foil strain gauge

- The piezo device is a transducer:

*“Transducer: converts input energy of one form into output energy of another”*

- The strain gauge is a *parametric* system i.e. input energy alters a parameter of another part of the system.

- Important Info

All transducers can be sensors, but not all sensors are transducers